

LIQUID NAILS FUZE*IT

Industrial Adhesive Installation Instructions



SOELBERG | INDUSTRIES

Key Features:

Hybrid technology bonds everything except polyethylene and polypropylene

Two times stronger than fasteners alone

Low VOC and very low odor

Certified by UL Environment to meet the GREENGUARD GOLD Standard as a low emitting material



4 easy to follow steps:

1 Wipe back of panels and substrate with a damp cloth prior to applying adhesive. All surfaces must be clean and free of loose particles.

2 Unscrew nozzle, cut tip of cartridge, replace nozzle and cut to desired bead size.

3 Insert into cartridge gun and apply a full tube per full sized panel of adhesive adequately covering the back of panel.

4 Press surfaces together within 10 minutes and apply pressure across the entire surface specifically the edges. Clamp, tape or brace panel to substrate if necessary until adhesive has set, typically 4 to 6 hours for porous surfaces.

Ensure panels are flat and aligned prior to adhesive curing. Improper placement will result in a permanent incorrect installation with possible bowing and / or cupping.

TIP: For better adhesion, the back surface of panel may be lightly sanded.

Watch Construction Adhesive in 6 Quick Steps video: liquidnails.com/en-US/products/construction-adhesive/fuze-it-all-surface-ln2000#

Note: not all walls are plumb, square nor flat. Modifications may be necessary. It is your responsibility to determine the best installation method for your project based upon site conditions. It is the sole responsibility of the installer to meet all building codes.

Adhesive Cartridge



Cartridge Gun